

INTERIOR TRIM AND ORNAMENTATION

FRONT SCUFF PLATE TRIM PANEL (G1904988)

REMOVAL AND INSTALLATION

76.13.81	FRONT ROCKER PANEL INNER TRIM - RENEW	ALL DERIVATIVES	0.10	USED WITHINS	
----------	---	--------------------	------	--------------	--

REMOVAL



NOTE:


Removal steps in this procedure may contain installation details.

1.



CAUTION:

Make sure that the component is correctly located on the locating dowels.



1.

To install, reverse the removal procedure.